

P_670 - P86A

www.bosch.com



Confidential

Table of Contents

I	[MEDC] Engine control devices software	43
1	[ASW] Application software	79
1.1	[Veh] Vehicle Functions	82
1.1.1	[CoVeh] Vehicle Coordinator	83
1.1.1.1	[CoVeh_SpdCoord] Vehicle co-ordinator - Speed co-ordination	86
1.1.1.2	[CoVeh_CalcTrqPrpLimErr] Vehicle co-ordinator - Calculation of TrqPrpLimErr	87
1.1.1.3	[CoME] Mechanical Energy Coordinator	89
1.1.1.3.1	[CoME_ShutOff] Mechanical energy co-ordinator	89
1.1.1.3.2	[CoME_DemCoord] Mechanical energy coordinator	103
1.1.1.4	[CoTE] Thermal Energy Coordinator	105
1.1.1.4.1	[CoTE_ThermDem] Coordinator Thermal Energy	105
1.1.1.5	[IgnLck] Ignition Lock Position	106
1.1.1.5.1	[IgnLck_SetData] Ignition Lock	106
1.1.1.6	[CoVeh_Axispoints] This component defines the interpolation nodes for CoVeh.	106
1.1.2	[VehMot] Vehicle Motion	107
1.1.2.1	[VehMot_Axispoints] This component defines the interpolation nodes for VehMot.	109
1.1.2.2	[CoVM] Vehicle Motion Coordinator	111
1.1.2.2.1	[CoVM_SpdCoord] Vehicle motion co-ordinator - speed co-ordination	111
1.1.2.3	[Prp] Propulsion	113
1.1.2.3.1	[Diff] Differential	114
1.1.2.3.1.1	[Diff_PlusPrtTrq] Differential protection torque - Error substitute reactions.	114
1.1.2.3.1.2	[Diff_TrqRat] Differential ratio-Error substitute reactions.	116
1.1.2.4	[VMD] Vehicle Motion Demand	118
1.1.2.4.1	[BrkPed] Brake Pedal	123
1.1.2.4.1.1	[BrkPed_SetData] Pedal Information	123
1.1.2.4.2	[AccPed] Accelerator Pedal	124
1.1.2.4.2.1	[AccPed_DoCoordOut] Accelerator pedal torque co-ordination	124
1.1.2.4.3	[CoVMD] Coordinator Vehicle Motion Demand	130
1.1.2.4.3.1	[CoVMD_SpdCoord] Speed Coordination of Vehicle Motion Demand	130
1.1.2.4.4	[VMD_Axispoints] Vehicle Motion Demand (VMD) axis points	131
1.1.3	[PT] Powertrain	132
1.1.3.1	[PT_Grip] Powertrain grip	142
1.1.3.2	[CoPT] Powertrain Coordinator	151
1.1.3.2.1	[CoPT_ThermDem] Driver train co-ordinator - Co-ordination of thermal requirements.	151
1.1.3.2.2	[PTODi] Powertrain Order Distributor	153
1.1.3.2.2.1	[PTODi_SpdCoord] Task distributor of the drive train - speed co-ordination	153
1.1.3.3	[Tra] Powertrain Stability Intervention	155
1.1.3.3.1	[Tra_TypelInfo] Gearbox type information	155
1.1.3.3.2	[Tra_GearInfo] Gearbox gear information	156
1.1.3.3.3	[Tra_Grip] Gearbox grip detection	158
1.1.3.3.4	[Tra_RtnIntfc] Gearbox engine speed interface	159
1.1.3.3.5	[Tra_Add] Gearbox additions	161
1.1.3.4	[Conv] Power Take-Off	163
1.1.3.4.1	[Conv_GripIntrck] Converter Grip Interlock	163
1.1.3.5	[PT_Axispoints] This component defines the supporting points for PT	163
1.1.4	[ESS] Electrical Supply System	165
1.1.4.1	[CoESS] Coordinator Electrical Supply System	166
1.1.4.1.1	[CoESS_Dem] Coordinator of electrical supply system.	166
1.1.4.1.2	[CoESS_Ord] Order of the electrical supply system coordinator	171
1.1.4.2	[Batt] Battery	172
1.1.4.2.1	[Batt_dataAcq] Battery	172
1.1.4.3	[Alt] Alternator	173

1.1.4.3.1	[Alt_Demand] Alternator	173
1.1.4.4	[ESS_Axispoints] This component defines the interpolation nodes for ESS.....	186
<hr/>		
1.1.5	[BdInt] Body and Interior	188
1.1.5.1	[DsplCtl] Body and Interior	189
1.1.5.1.1	[DrvInfo] Driver Information Module	190
1.1.5.1.1.1	[DrvInfo_Calc] Driver Information	190
<hr/>		
1.1.6	[TS] Thermal System	193
1.1.6.1	[CTM] Cabin Thermal Management	198
1.1.6.1.1	[CoCTM] Cabin Thermal System Coordinator.....	199
1.1.6.1.1.1	[CoCTM_ShutOff] Coordinator of the orders of the Cabin Thermal Management	199
1.1.6.1.1.2	[CoCTM_Demand] Coordinator of the demands of the Cabin Thermal Management	200
1.1.6.1.2	[AC] Air Condition	201
1.1.6.1.2.1	[AC_Demand] Air Condition Cooling Demand	201
1.1.6.1.2.2	[AC_DataAcq] Air Condition Compressor Data Aquisition	204
1.1.6.1.2.3	[ACComp] Air Condition Compressor	205
1.1.6.1.2.3.1	[ACComp_Demand] Air Condition Compressor Torque Demand ...	205
1.1.6.1.2.4	[ACCtl] Air Condition Control	206
1.1.6.1.2.4.1	[ACCtl_Demand] Air Condition Compressor Control	206
1.1.6.2	[ETM] Engine Thermal Management	208
1.1.6.2.1	[CoETM] Engine Thermal Management Coordinator.....	209
1.1.6.2.1.1	[CoETM_clgdem] Engine Thermal Management Cooling Demand ..	209
1.1.6.3	[ECUTM] ECU Thermal Management	221
1.1.6.3.1	[ECUTM_ClgDem] Engine control unit thermal management for the cooling demand	221
1.1.6.4	[CoTS] Thermal System Coordinator.....	225
1.1.6.4.1	[CoTS_MechDem] Thermal System Coordinator Mechanical Demand	225
1.1.6.4.2	[CoTS_ThermDem] Thermal System Coordinator Demand - Thermal demand	226
1.1.6.4.3	[CoTS_ShutOffAcs] Thermal System Coordinator Accessories Shut Off	228
1.1.6.5	[TSDa] Thermal System Data	230
1.1.6.5.1	[TSDa_tClnt] Coolant temperatures for the thermal supply system.	230
1.1.6.6	[Fans] Engine Fans	231
1.1.6.6.1	[Fans_ClgDem] Lüfter	231
1.1.6.6.2	[Fans_Trq] Fans Torque Demand	241
1.1.6.6.3	[FanCtl] Engine Fan Control	242
1.1.6.6.3.1	[FanCtl_Spd] Fan Control	242
1.1.6.7	[TS_Axispoints] This component defines the interpolation nodes for ETS.	243
<hr/>		
1.1.7	[GlbDa] Global Data	246
1.1.7.1	[GlbDa_SetData] Global Data: Set Data	248
1.1.7.2	[GlbDa_LSum] Global Data Total Distance.....	253
1.1.7.3	[GlbDa_TrqDem] Global Data Torque Demand	257
1.1.7.4	[GlbDa_ECUOnTime] Determination of the ECU-ON operating time	263
1.1.7.5	[GlbDa_RealTime] Real Time Processing	266
<hr/>		
1.2	[Eng] Engine Diesel	270
<hr/>		
1.2.1	[CoEng] Coordinator Engine	272
1.2.1.1	[CoEng_Mon] Shut-off coordinator.....	273
1.2.1.2	[CoEng_StEng] CoEng_stEngCalc	279
1.2.1.3	[CoEng_StrtCtl] Coordination of the engine related requirements for start.....	282
1.2.1.4	[CoEOM] Operating mode co-ordination and operating mode switchover	284
1.2.1.4.1	[CoEOM_Conf] Configuration for CoEOM.....	286
1.2.1.4.2	[CoEOM_Trans] Process for collecting the operating mode requests of the system.....	286
1.2.1.4.3	[CoEOM_Co] Operating mode coordinator	294
1.2.1.4.4	[CoEOM_SwtTSync] Time-synchronous component of the operating mode switchover	302
1.2.1.4.5	[CoEOM_SwtNSync] Angle-synchronous component of the operating mode switchover	307

1.2.1.4.6	[CoEOM_RmpCalc] Function for the takeover of the time-synchronous data in angle-synchronous data and calculation of the central ramp.....	308
1.2.1.4.7	[CoEOM_Lib] Library functions for the operating mode co-ordinator CoEOM	311
1.2.1.4.8	[CoEOM_Axispoints] Definition the number of axis points of application parameters for CoEOM.	321
1.2.1.5	[CoTemp] Temperature Coordinator	322
1.2.1.5.1	[CoTemp_DmAirDesVal] Setpoint calculation for relative cooling power demand of the engine	322
1.2.1.5.2	[CoTemp_TEngDesVal] Setpoint calculation for engine coolant temperature	323
1.2.1.6	[CoEng_Axispoints] This component defines the interpolation nodes for CoEng.	324
1.2.1.7	[CoEng_TransMode] Transient mode calculation	325
<hr/>		
1.2.2	[ETS] Engine Torque Structure	328
1.2.2.1	[ETS_GlbDef]	331
1.2.2.2	[ETS_Axispoints] This component defines the interpolation nodes for ETS.....	331
1.2.2.3	[CoETS] Coordinator Engine Torque Structure	334
1.2.2.3.1	[CoETS_stTrqLimCalc] Minimum limiting torque	334
1.2.2.3.2	[CoETS_TrqCalc] Engine torque coordination.....	340
1.2.2.4	[EngDem] Engine Demand	345
1.2.2.4.1	[EngDem_TrqLimCoord] limiting torque	345
1.2.2.4.2	[EngPrt] Engine Protection	351
1.2.2.4.2.1	[EngPrt_OvrSpd] Engine protection (overspeed detection)	351
1.2.2.4.2.2	[EngPrt_PrtLimMech] Engine mechanics protection	353
1.2.2.4.2.3	[EngPrt_PrtLimOvht] Engine over-heating protection	359
1.2.2.4.2.4	[EngPrt_TrqLimCalc] Resulting engine protection limitation	363
1.2.2.4.2.5	[EngPrt_TMFWSHOff] Quantity shut-off of the two-mass flywheel... ..	364
1.2.2.4.3	[EngReq] Engine Request	366
1.2.2.4.3.1	[EngReq_SmkLimCalc] Calculation of the smoke limit.....	366
1.2.2.4.3.2	[EngReq_InjLimCalc] Limiting torque from quantity.....	370
1.2.2.4.3.3	[EngReq_FullLdIncr] Full load increase	372
1.2.2.4.3.4	[EngReq_TrqLimCalc] Engine requirements.....	372
1.2.2.5	[ETSPth] Engine Torque Structure Path	374
1.2.2.5.1	[PthLead] Path Lead	375
1.2.2.5.1.1	[PthLead_TrqCalc] Engine torque calculation	375
1.2.2.5.2	[PthSet] Path Set.....	378
1.2.2.5.2.1	[PthSet_TrqCalc] Engine torque calculation	378
1.2.2.5.2.2	[PthSet_ovrRunCoord] Co-ordination of Over Run condition.....	383
1.2.2.6	[SpdGov] Speed governor.....	386
1.2.2.6.1	[SpdGov_trqCalc] Speed governor (torque and engine-speed interface).....	387
1.2.2.6.2	[EISGov] Engine interval speed governor	396
1.2.2.6.2.1	[EISGov_Governor] Engine interval speed governor (controller core)	397
1.2.2.6.2.2	[EISGov_SelectParameter] Engine interval speed governor (Select parameter and setpoint coordination)	408
1.2.2.6.2.3	[EISGov_SelectTrqLim] Engine interval speed governor (torque coordination)	419
1.2.2.6.3	[HLSDem] High-low speed demand	422
1.2.2.6.3.1	[HLSDem_SetPoint] High-low speed demand (setpoint calculation)	423
1.2.2.6.3.2	[HLSDem_SelectParameter] High-low speed demand (Select Parameter)	431
1.2.2.6.4	[GSHDem] Gear shift harmonization demand	449
1.2.2.6.4.1	[GSHDem_SelectParameter] Gear shift harmonization demand (Select Parameter and Setpoint Calculation)	449
1.2.2.6.5	[DiaDem] Diagnostic Demand	464
1.2.2.6.5.1	[DiaDem_SelectParameter] Diagnostic Demand (Select Parameter)	464
1.2.2.7	[TrqCnv] Torque conversion	473
1.2.2.7.1	[CnvLead] Torque Conversion Lead	474
1.2.2.7.1.1	[CnvLead_trq2q] Conversion of torque into quantity	474
1.2.2.7.2	[CnvSet] Torque Conversion Set	476
1.2.2.7.2.1	[CnvSet_trq2q] Conversion of torque into quantity for Set path ...	476
1.2.2.8	[TrqMod] Torque Model	481
1.2.2.8.1	[ActMod] Model Actual Torque	482
1.2.2.8.1.1	[ActMod_Q2Trq] Conversion of quantity into torque	482

1.2.2.8.1.2	[ActMod_trqCalc] Calculation of crankshaft torque	483
1.2.2.8.2	[RngMod] Model Torque Range	485
1.2.2.8.2.1	[RngMod_TrqFrcCalc] Friction torque calculation	485
1.2.2.8.2.2	[RngMod_TrqCalc] Torque interval	488
1.2.2.8.2.3	[RngMod_TrqFrcAdpdt] Torque loss adaptation	490
1.2.2.8.2.4	[RngMod_trqSpdCrv] Engine curve	495
1.2.2.8.3	[PhyMod] Physical Torque Model	496
1.2.2.8.3.1	[PhyMod_CalcCor] Calculation of the correction quantity and formation of the correction factors.	496
1.2.2.8.3.2	[PhyMod_GenCur] Basis for quantity / torque conversion	503
1.2.2.8.3.3	[PhyMod_GenCur_Lib] Library function used in determination of the current conversion curve	505
1.2.2.8.3.4	[PhyMod_PwrEntryCalc] heat entry of the engine into the coolant as power	506
1.2.2.8.3.5	[PhyMod_OpModeSelect] Determining operating modes	507
1.2.2.8.3.6	[PhyMod_OpModeSelectNSync] Angle-synchronous operating mode determination	509
<hr/>		
1.2.3	[EngDa] Engine Data	510
1.2.3.1	[EngDa_TEng] Engine temperature	511
1.2.3.2	[EngDa_TiEngOn] Determination of the engine-ON operating time ..	516
1.2.3.3	[EngDa_TiEngOff] Calculation of Engine Off Time	517
1.2.3.4	[EngDa_PwrEng] Supply of Engine power	518
1.2.3.5	[EngDa_Axispoints] This component defines the interpolation nodes for EngDa.	519
<hr/>		
1.2.4	[GsSys] Gas System	520
1.2.4.1	[AirSys] Air System	521
1.2.4.1.1	[AirSys_AxisPoints] AirSys Axis Points	524
1.2.4.1.2	[AirSys_AxisPointsCust] AirSys Axis Points	525
1.2.4.1.3	[AirSys_GlbDef] Global AirSys definitions	525
1.2.4.1.4	[AirSys_AirTemp] Temperature induction system	528
1.2.4.1.5	[AirSys_Lib] Function library for the air system	530
1.2.4.1.6	[CoAS] Coordinator Air System	548
1.2.4.1.6.1	[CoAS_RlsCmpn] Actuator coordinator	548
1.2.4.1.7	[BstCtl] Boost Control	551
1.2.4.1.7.1	[PCR] Pressure Control Regulator	553
1.2.4.1.7.1.1	[PCR_AxisPoints] PCR Axis Points	556
1.2.4.1.7.1.2	[PCR_AxisPointsCust] PCR Axis Points	560
1.2.4.1.7.1.3	[PCR_GlbDef] Global PCR definitions	560
1.2.4.1.7.1.4	[PCR_Co] Interface coordinator	561
1.2.4.1.7.1.5	[PCR_DesValCalc] Boost-pressure setpoint calculation	575
1.2.4.1.7.1.6	[PCR_TrjGenr] Trajectory calculation of the charger speeds	595
1.2.4.1.7.1.7	[PCR_InvTCMod] Calculation of the precontrol values for the area controller	617
1.2.4.1.7.1.8	[PCR_Obsvr] Observer	627
1.2.4.1.7.1.9	[PCR_TCARGov] Area controller for the closed-loop boost-pressure control	638
1.2.4.1.7.1.10	[PCR_MsFlwCalc] Calculation of the induction air-mass flows	671
1.2.4.1.7.1.11	[PCR_Mon] Boost-pressure control - monitoring and switch-off	678
1.2.4.1.8	[EGRCtl] Exhaust Gas Recirculation Control	700
1.2.4.1.8.1	[AirCtl] Air Control	702
1.2.4.1.8.1.1	[AirCtl_AxisPoints] AirCtl Axis Points	704
1.2.4.1.8.1.2	[AirCtl_AxisPointsCust] AirCtl Axis Points	707
1.2.4.1.8.1.3	[AirCtl_GlbDef] Global AirCtl definitions	707
1.2.4.1.8.1.4	[AirCtl_Co] Signal conditioning of the AirCtl signal	708
1.2.4.1.8.1.5	[AirCtl_DesValCalc] Exhaust-gas recirculation control - setpoint formation	725
1.2.4.1.8.1.6	[AirCtl_RatDesValCalc] Formation of EGR rate setpoint	750
1.2.4.1.8.1.7	[AirCtl_TrjGenr] Generating trajectories for air mass and exhaust-gas recirculation setpoints	769
1.2.4.1.8.1.8	[AirCtl_InvManfMod] Inverse model of the induction volume	784
1.2.4.1.8.1.9	[AirCtl_TVAArGov] PI-controller for the throttle valve	788
1.2.4.1.8.1.10	[AirCtl_EGRArGov] PI-controller for the exhaust-gas recirculation valve	792
1.2.4.1.8.1.11	[AirCtl_Mon] Closed-loop exhaust-gas recirculation control - monitoring and switch-off	796
1.2.4.1.8.2	[EGRClg] Exhaust Gas Recirculation Cooling	826

1.2.4.1.8.2.1	[EGRC]g_CtlValCalc] EGR cooler bypass control value calculation (function)	826
1.2.4.2	[ASMod] Air System Model	835
1.2.4.2.1	[ASMod_Co] Interface coordinator	836
1.2.4.2.2	[ASMod_VolEff] Volumetric efficiency	844
1.2.4.2.3	[ASMod_IntMnfLP] Intake manifold, low pressure	852
1.2.4.2.4	[ASMod_IndVol] Induction volume	855
1.2.4.2.5	[ASMod_DetCylCh] Determination of cylinder charge	864
1.2.4.2.6	[ASMod_Eng] Engine	873
1.2.4.2.7	[ASMod_Lib] Function library for the air system model	915
1.2.4.2.8	[ASMod_TempCatMod] Exhaust-gas temperature model for catalysts	922
1.2.4.2.9	[ASMod_TempTrbn] Turbocharger exhaust-gas temperature model	949
1.2.4.2.10	[ASMod_TempPipe] Tube temperature model	953
1.2.4.2.11	[ASMod_TempStrtCalc] Start temperature calculation exhaust-gas system	959
1.2.4.2.12	[ASMod_TempPipeSlw] Tube temperature model	968
1.2.4.2.13	[ASMod_PresPipe] Model of exhaust-gas back-pressure	975
1.2.4.2.14	[ASMod_TempPFlt] Particulate filter temperature model	979
1.2.4.2.15	[ASMod_LamSens] Lambda sensor model	986
1.2.4.2.16	[ASMod_AxisPoints] ASMod supporting coordinates	988
1.2.4.2.17	[ASMod_AxispointsCust] ASMod Axis Points	995
1.2.4.2.18	[ASMod_GlbDef] Global ASMod definitions	995
1.2.4.2.19	[ASMod_Cmpr] Compressor	1023
1.2.4.3	[EGSys] Exhaust Gas System	1038
1.2.4.3.1	[CoES] AVS coordinator for LSU-packages	1039
1.2.4.3.1.1	[CoES_AVSCoLSU] AVS coordinator of the LSU-relevant components	1039
1.2.4.3.2	[SmkLim] Smoke Limitation	1043
1.2.4.3.2.1	[SmkLim_AirMsSel] Air mass coordinator for smoke limitation	1045
1.2.4.3.2.2	[SmkLim_FullLdRgl] Full-load control for smoke limitation	1046
1.2.4.3.2.3	[SmkLim_InjMassLim] Calculation of the smoke limitation quantity	1047
1.2.4.3.3	[DewDet] Dew Point Detection	1058
1.2.4.3.3.1	[DewDet_HtrRls] Dew-point detection	1058
1.2.4.3.4	[T3Lim] Exhaust gas temperature limitation at full load	1066
1.2.4.3.4.1	[T3Lim_InjMassLim] Limitation of the injection quantity	1069
1.2.4.3.5	[EGT] EGT	1089
1.2.4.3.5.1	[LamCtl] Lambda governor	1090
1.2.4.3.5.1.1	[LamCtl_Ini] LamCtl Initialisation	1091
1.2.4.3.5.1.2	[LamCtl_DesVal] Lambda Setpoint Value Coordination	1092
1.2.4.3.5.1.3	[LamCtl_Gov] Lambda governor	1094
1.2.4.3.5.1.4	[LamCtl_Mon] Lambda control monitoring	1100
1.2.4.3.5.1.5	[LamCtl_AdapPreCtl] Adaptive stationary lambda precontrol correction	1104
1.2.4.3.5.2	[NOxCat] NOx Catalyst	1113
1.2.4.3.5.2.1	[NSC] NOx Storage Catalyst	1114
1.2.4.3.5.2.1.1	[NSC_Ini] NSC Initialisation	1115
1.2.4.3.5.2.1.2	[NSC_RMDet] NOx storage catalyst - detection of rich-mixture operation	1116
1.2.4.3.5.2.1.3	[NSC_DesValCalc] Lambda setpoint value	1122
1.2.4.3.5.2.1.4	[NSCMon] NSC Monitoring	1134
1.2.4.3.5.2.1.4.1	[NSCMon_NOxRM] Monitoring of NOx signal during rich-mixture operation	1135
1.2.4.3.5.2.1.4.2	[NSCMon_LamBinRM] Monitoring Binary Lambda during rich-mixture operation	1141
1.2.4.3.5.2.1.4.3	[NSCMon_SysFailDet] Monitoring of the NSC system errors	1146
1.2.4.3.5.2.1.4.4	[NSCMon_Sig] Signal conditioning for monitoring the NSC	1149
1.2.4.3.5.2.1.4.5	[NSCMon_LamDynRM] Monitoring of lambda signals during rich-mixture operation	1156
1.2.4.3.5.2.1.4.6	[NSCMon_NOxSlip] Monitoring of the NOx slip	1169
1.2.4.3.5.2.1.4.7	[NSCMon_SOvLdDet] Monitoring for too high a sulfur load of the NSC	1180
1.2.4.3.5.2.1.4.8	[NSCMon_Co] Coordinator of NSC Monitoring	1188
1.2.4.3.5.2.1.4.9	[NSCMon_Char] Monitoring the NOx storage catalyst characteristic	1192
1.2.4.3.5.2.1.4.10	[NSCMon_RdcMsCons] Monitoring of the reducing agent consumption for NSC diagnosis	1194
1.2.4.3.5.2.1.5	[NSCLd] NSC load	1207

1.2.4.3.5.2.1.5.1	[NSCLd_CatAge] NSC ageing model	1207
1.2.4.3.5.2.1.5.2	[NSCLd_SAM] System Adaptation Manager	1209
1.2.4.3.5.2.1.5.3	[NSCLd_SOx] NSCLd, SOx saturation model	1221
1.2.4.3.5.2.1.5.4	[NSCLd_NOxLd] NSC, NOx load model	1225
1.2.4.3.5.2.1.5.5	[NSCLd_NOxUnld] NSC, NOx unloading model	1234
1.2.4.3.5.2.1.6	[NSCRgn] NSC Regeneration	1241
1.2.4.3.5.2.1.6.1	[NSCRgn_Dem] Regeneration demand for NOx storage catalyst ...	1242
1.2.4.3.5.2.1.6.2	[NSCRgn_RlsLogic] Release logic for the regeneration of the NOx storage catalyst	1274
1.2.4.3.5.2.1.6.3	[NSCRgn_StCalc] Calculation of the NSC state	1312
1.2.4.3.5.2.1.7	[NSCSrv] NSC Service Concept	1323
1.2.4.3.5.2.1.7.1	[NSCSrv_Lib] NSC Service Library	1324
1.2.4.3.5.2.1.7.2	[NSCSrv_RgnCond] NSC Service Regeneration - Conditions	1329
1.2.4.3.5.2.1.7.3	[NSCSrv_Rgn] DeSOx service regeneration	1336
1.2.4.3.5.3	[OxiCat] Monitoring of the oxidation catalyst	1352
1.2.4.3.5.3.1	[OxiCat_HCCnvRatCalc] Oxidation catalyst HC conversion rate calculation	1353
1.2.4.3.5.3.2	[OxiCat_MonPas] Passive monitoring of the oxidation catalyst	1357
1.2.4.3.5.4	[PFIt] Particulate Filter	1367
1.2.4.3.5.4.1	[PFIt_TempDesVal] Desired temperature value of the Particulate Filter	1370
1.2.4.3.5.4.2	[PFIt_Mon] Particulate filter monitoring	1374
1.2.4.3.5.4.3	[PFIt_Ini] Initialization of the particulate filter	1394
1.2.4.3.5.4.4	[PFIt_NMinCalc] Minimal engine speed calculation	1397
1.2.4.3.5.4.5	[PFItPOp] Particulate Filter Point Of Operation	1400
1.2.4.3.5.4.5.1	[PFItPOp_RngDet] Calculation of the operating state of the particulate filter (This section only contains the range detection)	1400
1.2.4.3.5.4.5.2	[PFItPOp_SigCond] Particulate filter operating point - signal conditioning	1413
1.2.4.3.5.4.6	[PFItRgn] Particulate Filter Regeneration	1419
1.2.4.3.5.4.6.1	[PFItRgn_CmpnPrt] Regeneration interruption	1422
1.2.4.3.5.4.6.2	[PFItRgn_Dem] Particulate filter regeneration demand	1429
1.2.4.3.5.4.6.3	[PFItRgn_Co] Particulate filter regeneration coordinator	1445
1.2.4.3.5.4.6.4	[PFItRgn_AltLdIncr] Load increase due to activation of electrical consumers for DPF regeneration	1460
1.2.4.3.5.4.6.5	[PFItRgn_JmpCondDet] Particulate filter jump condition detection	1465
1.2.4.3.5.4.7	[PFItLd] Particulate Filter load	1471
1.2.4.3.5.4.7.1	[PFItLd_Co] Particulate filter load calculation coordinator	1472
1.2.4.3.5.4.7.2	[PFItLd_SotSim] Particulate filter loading calculation - Particulate mass simulation	1478
1.2.4.3.5.4.7.3	[PFItLd_SotFlwRstn] Particulate filter loading calculation - Particulate mass and flow resistance	1491
1.2.4.3.5.4.7.4	[PFItLd_SotAsh] Particulate filter load calculation - volume of ash ..	1503
1.2.4.3.5.4.8	[PFItSrv] Particulate filter service	1508
1.2.4.3.5.4.8.1	[PFItSrv_RgnCond] Particulate filter service generation - conditions ..	1509
1.2.4.3.5.4.8.2	[PFItSrv_Rgn] Particulate filter service regeneration	1521
1.2.4.3.5.4.8.3	[PFItSrv_Lib] Particulate filter service library	1534
1.2.4.3.6	[ETCt] Exhaust Temperature Control	1541
1.2.4.3.6.1	[ETCt_Ini] Initialization of the exhaust-gas temperature controller ..	1542
1.2.4.3.6.2	[ETCt_Rls] Activation of the exhaust-gas temperature controller ..	1543
1.2.4.3.6.3	[ETCt_Mon] Monitoring the exhaust-gas temperature controller ...	1550
1.2.4.3.6.4	[ETCt_CalcTempDes] Exhaust gas temperature control - desired temperature calculation	1555
1.2.4.3.6.5	[ETCt_InrLp] Exhaust-gas temperature controller - inner control loop	1558
1.2.4.3.6.6	[ETCt_OutrLp] Exhaust-gas temperature controller - outer control loop	1571
1.2.5	[InjSys] Injection System CR	1582
1.2.5.1	[InjSys_Co] Co-ordination of the interfaces	1582
1.2.5.2	[InjSys_CtlQnt] Control quantities	1584
1.2.5.3	[InjSys_GlbDef] Global system constant for the InjSys package	1590
1.2.5.4	[InjSys_ThmMng] Thermal management	1591
1.2.5.5	[InjCtl] Injection control	1592
1.2.5.5.1	[InjCtl_qCo] Quantity co-ordination	1592
1.2.5.5.2	[FBC] Fuel quantity Balancing Control	1595
1.2.5.5.2.1	[FBC_Equal] Smooth-running controller	1596
1.2.5.5.2.2	[FBC_WheelLrn] FBC	1604

1.2.5.5.3	[FMA] Fuel Meanvalue Adaptation	1608
1.2.5.5.3.1	[FMA_CtlCalc] Fuel quantity mean value adaptation - fuel quantity error calculation	1608
1.2.5.5.4	[FMO] Fuel Mass Observer	1609
1.2.5.5.4.1	[FMO_Obsvr] Observer of the lambda signal	1614
1.2.5.5.4.2	[FMO_CorValCalc] Correction value calculation of the observer ...	1622
1.2.5.5.4.3	[FMO_ErrMod] Adaptive error model of the observer	1635
1.2.5.5.4.4	[FMO_RlsAdaptFst] Adaptation release	1639
1.2.5.5.5	[InjCrv] Injection curve	1653
1.2.5.5.5.1	[InjCrv_Co] Injection co-ordinator	1656
1.2.5.5.5.2	[InjCrv_CoPILRls] Release of the pilot injections	1666
1.2.5.5.5.3	[InjCrv_CoPILRlsAddCor] Customer specific corrections for Pil release in the injection co-ordinator	1668
1.2.5.5.5.4	[InjCrv_CoPILRlsCor] Corrections for Pil release in the injection co-ordinator	1670
1.2.5.5.5.5	[InjCrv_CoPILRlsOpRng] Selecting the operating range of the Pil release in the injection co-ordinator	1672
1.2.5.5.5.6	[InjCrv_CoPolRls] Post injection release structure	1675
1.2.5.5.5.7	[InjCrv_CoPolRlsAddCor] Customer specific corrections for Pol release in the injection co-ordinator	1681
1.2.5.5.5.8	[InjCrv_LamPreCtl] Lambda precontrol by quantity shift	1682
1.2.5.5.5.9	[InjCrv_MI1] Main injection	1688
1.2.5.5.5.10	[InjCrv_MI1AddCor] Calculation of additional corrections for the main injection	1697
1.2.5.5.5.11	[InjCrv_MI1Cor] Calculation of the main injection 1 (MI1) correction value	1703
1.2.5.5.5.12	[InjCrv_MI1CSCCor] Correction of MI1 by the CSC	1710
1.2.5.5.5.13	[InjCrv_MI1SOEAirMsCor] Angle correction of the main injection based on the air mass deviations	1710
1.2.5.5.5.14	[InjCrv_Pil] Pilot injections	1711
1.2.5.5.5.15	[InjCrv_PilAddCor] Calculation of additional (customer specific) corrections for the pilot injections	1732
1.2.5.5.5.16	[InjCrv_PilCor] Environmental corrections of the pilot injections ...	1739
1.2.5.5.5.17	[InjCrv_PilSet] Quantity and start of energising setpoint values of pilot injections	1753
1.2.5.5.5.18	[InjCrv_Pol1] Post injection 1	1756
1.2.5.5.5.19	[InjCrv_Pol1AddCor] Customer specific corrections for post injection 1	1767
1.2.5.5.5.20	[InjCrv_Pol1Cor] Environmental corrections of post injection 1 (Pol1)	1768
1.2.5.5.5.21	[InjCrv_Pol1Set] Calculation of the setpoint values for post injection 1	1773
1.2.5.5.5.22	[InjCrv_Pol2] Post injection 2	1774
1.2.5.5.5.23	[InjCrv_Pol2AddCor] Customer specific corrections for post injection 2	1789
1.2.5.5.5.24	[InjCrv_Pol2Cor] Environmental corrections of post injection 2 (Pol2)	1792
1.2.5.5.5.25	[InjCrv_Pol2Set] Setpoint calculation for post injection 2	1798
1.2.5.5.5.26	[InjCrv_Pol3] Post injection 3	1802
1.2.5.5.5.27	[InjCrv_Pol3AddCor] Customer specific corrections for post injection 3	1814
1.2.5.5.5.28	[InjCrv_Pol3Cor] Environmental corrections of post injection 3 (Pol3)	1816
1.2.5.5.5.29	[InjCrv_Pol3Set] Setpoint calculation for post injection 3	1822
1.2.5.5.5.30	[InjCrv_PoLib] Library functions for the post injections	1824
1.2.5.5.5.31	[InjCrv_QntLim] Limitation of main and post injection quantities ..	1831
1.2.5.5.5.32	[InjCrv_QntMinLib] Minimum injection quantity	1848
1.2.5.5.5.33	[InjCrv_ShOffTst] Shut-off test	1849
1.2.5.5.5.34	[InjCrv_SwtInhCorFuncTst] Dynamic test of the disabling of the correction functions	1852
1.2.5.6	[InjUn] Injection unit	1855
1.2.5.6.1	[InjUn_StrtTst] Errors at engine start relevant to the injection system	1855
1.2.5.6.2	[HPUn] High pressure unit	1859
1.2.5.6.2.1	[HPUn_Co] High pressure unit	1859
1.2.5.6.2.2	[HPUn_QntBallInjLim] Injection shut-off based on the fuel quantity balance	1861
1.2.5.6.3	[Rail] Rail	1863
1.2.5.6.3.1	[Rail_CtlLoop] High pressure control	1865
1.2.5.6.3.2	[Rail_CtlLoopLimMeUn] Limitations for pressure control by metering unit	1888

1.2.5.6.3.3	[Rail_CtlLoopLimPCV] Limits for pressure control by pressure control valve	1889
1.2.5.6.3.4	[Rail_CtlLoopParaMeUn] Parameters for pressure control by metering unit	1890
1.2.5.6.3.5	[Rail_CtlLoopParaPCV] Parameters for pressure control by pressure control valve	1894
1.2.5.6.3.6	[Rail_CtlTypeSwT] Switchover conditions for the CPC and 2-actuator governing concept	1897
1.2.5.6.3.7	[Rail_MonCPC] Rail pressure monitoring during switchover to CPC governing	1902
1.2.5.6.3.8	[Rail_MonMeUn] Rail pressure monitoring during pressure control by metering unit	1906
1.2.5.6.3.9	[Rail_MonPCV] Rail pressure monitoring during pressure control by pressure control valve	1916
1.2.5.6.3.10	[Rail_PGovSetup] Configuration of the rail component	1924
1.2.5.6.3.11	[Rail_PreCtlMeUn] Precontrol for high pressure control by metering unit	1925
1.2.5.6.3.12	[Rail_PreCtlPCV] Precontrol for high pressure control by pressure control valve	1929
1.2.5.6.3.13	[Rail_SetPoint] Calculation of the rail pressure setpoint	1932
1.2.5.6.3.14	[Rail_SetPointAddCor] Project specific calculation for rail pressure setpoint	1941
1.2.5.6.3.15	[Rail_SetPointCor] Calculating corrections for the rail pressure setpoint	1944
1.2.5.6.3.16	[Rail_SetPointTst] Engine test diagnostic function setpoint pressure test	1947
1.2.5.6.3.17	[Rail_SetSubst] External specification for rail pressure setpoint ...	1952
1.2.5.6.3.18	[Rail_TempLim] Torque limitation based on the fuel temperature ..	1955
1.2.5.6.3.19	[Rail_ZFCLib] Zero fuel calibration interventions in the rail pressure setpoint formation	1957
1.2.5.6.3.20	[Rail_HiPresTst] High pressure test engine test diagnostic function	1960
1.2.5.7	[FISys] Low pressure stage	1973
1.2.5.7.1	[FISys_CalcCnvFac] Calculation of the fuel density	1973
1.2.5.7.2	[FISys_FICons] Calculation of the fuel consumption	1975
1.2.5.7.3	[FISys_Deflate] Deflation of the low pressure stage	1978
1.2.5.7.4	[FISys_DeflateTst] Rail deflation test	1981
1.2.5.7.5	[FISys_DetFItnk] Function for the detection of an empty fuel tank ..	1983
1.2.5.7.6	[FISys_FIPres] Function for the calculation of the inlet fuel pressure in the high pressure pump	1986
1.2.5.7.7	[PSPCtl] Presupply pump control	1987
1.2.5.7.7.1	[PSPCtl_Co] Electric presupply pump logic	1987
1.2.6	[CmbSys] Combustion system	1992
1.2.6.1	[CmbChb] Combustion Chamber	1993
1.2.6.1.1	[ESBMon] Engine Speed Based Monitoring	1994
1.2.6.1.1.1	[MisfDet] Misfire detection	1995
1.2.6.1.1.1.1	[MisfDet_Misfire] Misfire detection	1996
1.2.6.1.1.1.2	[MisfDet_MisfireEn] Activation of Misfire detection	2001
1.2.6.1.2	[PHC] Enabling logic PHC-operation	2004
1.2.6.1.2.1	[PHC_Rls] Release conditions PHC-mode	2004
1.2.6.1.2.2	[PHC_RlsSlow] Slowly variable release conditions for PHC operation	2010
1.2.6.1.2.3	[PHC_State] State machine PHC release	2012
1.2.6.2	[GlowCtl] Glow Control	2017
1.2.6.2.1	[GlowCtl_AxisPoints] GlowCtl axis points	2018
1.2.6.2.2	[GlowCtl_StM] Glow time control state machine	2019
1.2.6.2.3	[GlowCtl_ActrCtl] Glow actuator control	2030
1.2.6.2.4	[GlowCtl_PwrCtl] Glow power control	2034
1.2.7	[StSys] Start system	2045
1.2.7.1	[StSys_Strt] Starting cut-out	2045
1.2.7.2	[StSys_StrtBas] Starting base torque	2048
1.2.7.3	[StSys_StrtRmp] Starting ramp	2050
1.2.7.4	[StSys_TrqShutOff] Starting torque shut-off	2054
1.2.7.5	[StSys_StrtCtl] Switching on and off of the starter	2054
1.2.7.6	[StSys_AddCor] Starting torque correction	2071
1.2.8	[EngM] Engine Mechanics	2072
1.2.8.1	[EMCtl] Engine Mount Control	2073
1.2.8.1.1	[EMCtl_ValCalc] Engine Mount Dampener Control	2073

2	[ASV] Application Supervisor	2076
2.1	[ESC] Engine Synchronous Schedule Controller with process limitation	2077
2.1.1	[ESC_TaskLink] Activation Of Speed- Synchronous Tasks	2077
2.1.2	[ESC_SeqSched] Scheduling engine speed-synchronous processes	2080
2.1.3	[ESC_Stack] Provision of sample time DT	2088
2.2	[SyC] System control	2091
2.2.1	[SyC_Main] System/ECU state	2091
2.2.2	[SyC_PreDrv] PreDrive control	2094
2.2.3	[SyC_PostDrv] PostDrive control	2097
2.2.4	[SyC_Shutdown] Shutdown Control	2100
2.2.5	[SyC_CalWakeup] System control for CalWakeup	2100
2.2.6	[SyC_Deadline] Deadline check	2100
2.2.7	[SyC_UnderVltg] Handling of 5V-Undervoltage	2101
2.2.8	[SyC_StopCnt] Acquiring ECU off time	2102
2.3	[Mo] Monitoring Function	2107
2.3.1	[Mo_Glbl] Global Monitoring Functions Data	2108
2.3.2	[MoExe] Monitoring Execution Control	2111
2.3.2.1	[MoExe_Co] Monitoring Execution Control	2111
2.3.3	[MoC] Monitoring Controller Level 3	2112
2.3.3.1	[MoCADC] ADC monitoring	2113
2.3.3.1.1	[MoCADC_Co] ADC monitoring	2113
2.3.3.2	[MoCCom] Communication monitoring module	2125
2.3.3.2.1	[MoCCom_Co] Query-response communication	2125
2.3.3.3	[MoCCPU] Command test	2134
2.3.3.3.1	[moccpu_co] Instruction test	2134
2.3.3.4	[MoCGPTA] GPTA monitoring	2135
2.3.3.4.1	[MoCGPTA_Co] GPTA-Monitoring	2135
2.3.3.5	[MoCMem] Cyclic memory test	2136
2.3.3.5.1	[MoCMem_Co] Cyclical memory test	2136
2.3.3.6	[MoCPCP] PCP monitoring	2145
2.3.3.6.1	[MoCPCP_Co] PCP monitoring	2145
2.3.3.7	[MoCPFC] Program execution monitoring	2146
2.3.3.7.1	[MoCPFC_Co] Program flow check	2146
2.3.3.8	[MoCRAM] Complete memory test for the RAM memory range	2148
2.3.3.8.1	[MoCRAM_Co] Complete RAM check	2148
2.3.3.9	[MoCROM] Complete memory test for the ROM memory range	2153
2.3.3.9.1	[MoCROM_Co] Complete ROM check	2153
2.3.3.10	[MoCSOP] Test of redundant shut-off paths	2158
2.3.3.10.1	[MoCSOP_Co] Test of redundant shut-off paths	2158
2.3.4	[MoF] Monitoring Function Level 2	2171
2.3.4.1	[MoFDev] Monitoring Function Devices	2173
2.3.4.1.1	[MoFVSS] Monitoring Function Vehicle Speed Sensor	2174
2.3.4.1.1.1	[MoFVSS_Co] Monitoring of vehicle speed signal	2174
2.3.4.1.2	[MoFESpd] Monitoring Function Engine Speed	2194
2.3.4.1.2.1	[MoFESpd_Co] Engine speed monitoring for function monitoring	2194
2.3.4.1.3	[MoFTra] Monitoring Function TSC	2203
2.3.4.1.3.1	[MoFTra_Co] Gearbox intervention - Monitoring for function monitoring	2203
2.3.4.1.4	[MoFDCS] Monitoring Function DCS	2224
2.3.4.1.4.1	[MoFDCS_Co] MSR - Intervention - Monitoring for function monitoring	2224
2.3.4.1.5	[MoFACC] Monitoring Function Adaptive Cruise Control	2233